



Marshalls

Creating Better Spaces

INSTALLATION DETAILS FOR WEATHERPOINT 365 JOINTING COMPOUND

Health and Safety Information

Safe working practices should be employed at all times during the construction process and all necessary Personal Protective Equipment (PPE) should be worn.

Installation

To use Weatherpoint 365, rake out any excess mortar in the joints, and create drainage holes through the bedding mortar at 200mm intervals. This can be achieved by:

- Using a dowel or similar whilst the bedding mortar is wet or afterwards with a drill. The diameter of the hole should be in relation to the joint thickness.

Wet it.....Brush it....Strike it!



Whether you are laying Weatherpoint 365 in the rain or dry, always thoroughly saturate the paved area with a hose or watering can and leave for 10 minutes to absorb. Re-saturate before applying Weatherpoint 365. Failure to wet the paving could temporarily stain the paving's surface.



Open the tub and cut open the vacuum bag. Empty the Weatherpoint 365 material onto the paving surface.



Brush Weatherpoint 365 material into the joint areas with a stiff sweeping brush, occasionally hosing with water to allow Weatherpoint 365 to flow into joints. Ensure that the joint void is completely full.



Sweep off any excess Weatherpoint 365 and store (see detailed instructions on tub). Strike off the joint using a standard brick jointer, top up any sagging joints with more Weatherpoint 365 and strike off again.

Failure to remove the jointing compound from the surface of the paving will result in temporary staining of the paving.



To finish the process, spray the surface area with a wide angle spray and clean the remaining Weatherpoint 365 with a soft bristle brush.



If you require a smoother finish to your joint, wait for the paving to dry out slightly and iron the joint using a standard brick jointer, leave to cure.

Contact Us

- Marshalls Group Technical Services on 0370 411 2233, or by email on grouptechnicalservices@marshalls.co.uk